


## Removing, cleaning, restaging and reinstalling your twin screw extruder screw set Advice for removing screw elements from shafts.

By Bert Elliott and Bill Novak, Leistritz

If at all possible, work on the screws immediately after use while they are still hot, or put the screw shaft assembly back in the ZSE twin screw extruder to heat the shafts and elements together. Allowing the elements time to heat up slowly (about 20 minutes) is always better. The idea would then be to remove the screw tips and slide off a portion of the screws onto a raised table or cart right at the end of the machine.



Co-rotating and counter-rotating twin screw sets

If the shafts must be removed from the machine and heated with a torch, please use caution and heat evenly all the way around the element. Do not let the elements change color! This can affect the metallurgy. Warm them instead of burning them. Use a rosebud acetylene torch and be patient. While the elements are hot, use a punch made from wood or hard plastic to push the elements from the shaft. An aluminum or brass drift pin can also be used but caution is always advisable when impacting the elements. An electric impact hammer may be purchased that will significantly help. Follow these steps:

- USE HOT GLOVES
- Support the screw shaft assemblies at enough points so that they do not bend
- Unscrew the tips to remove the elements
- While using the rosebud pull the element from the shaft
- More difficult elements may need friendly persuasion
- Angle the appropriate punch against the flight of the element
- Use a rubber mallet and hammer while heating until the element moves
- Remove one at a time and be sure brush clean or scrape the exposed shaft

An impact hammer is a noisy device, and works very well at breaking loose stuck screw elements. The above steps still need to be followed for screw removal, but additionally:

- Wear hearing protection!
- Modify the device to accept a brass tip
- While heating, apply hammering action to the flight of the element

### **Screw element cleaning and inspection:**

Best results may be obtained by at least doing an initial cleaning with a steel wire brush or copper gauze as the screws are removed from the machine. Once they are brushed off, the elements may be placed in an oven or fluidized bath to clean them. Don't exceed the temperature rating of the metallurgy!

If there is black, baked-on, degraded material, some form of mechanical abrasion will be required to remove it. Brass or copper brushes are often too soft, and won't get baked on degraded materials off. If this is the case:

- WEAR GLOVES AND EYE PROTECTION
- Use a stiff steel wire brush wheel on a bench grinder
- Use a belt sander (small air-powered portable belt sanders work well)
- Use a sandblaster or dry-ice blaster
- Clean element key ways and splined bores

Once the elements are clean, inspect them for hairline cracks, and any nicks or gouges. Nicks and gouges may become cracks and should be gently smoothed out with a file or grinding disc.

In addition, end faces should be "stoned" or sanded smooth with 320 grit sandpaper. This should be done on a level flat mechanical surface such as a marble slab or thick steel plate. Lay emery cloth or 320 grit paper flat on the surface and work the face of the element in a figure eight pattern applying only enough pressure to evenly clean the element face. If wear rate is to be documented, the dimensions should be checked with a micrometer and recorded. Elements with hairline cracks should be discarded. Damaged elements break apart while running and have been known to twist shafts, wreck barrels, and cause catastrophic failure to gearboxes.

### **Rebuilding the screw shaft assembly:**

It bears mentioning that the screw components have sharp edges and can cause injury if not handled properly. Leather palm gloves or gloves made from other cut resistant fabrics should be worn whenever handling screw elements.

- Clean the shafts with a wire brush to remove any remaining foreign material. This includes the coupling splines
- Inspect the screw elements and use the above procedure to clear any foreign material
- An anti-seize compound should be used every time elements are assembled on a shaft. A candidate is Gleitmo 820, see: [www.fuchs-lubritech.com](http://www.fuchs-lubritech.com). It is a white grease that does not degrade at high temperatures
- Anti-seize should coat all shaft surfaces, but be used sparingly (wipe on-wipe off). Any anti-seize that builds up on an element end faces while installing on the shaft must be removed
- Position both shafts as a pair parallel to each other. If the shaft clamping block is available use this fixture to hold the shafts in the correct timing position
- If the fixture is unavailable, clamp the shaft ends between two wood blocks at the correct shaft center line distance
- The screw elements will now be installed as pairs. The relative position between the screw elements and the shaft set screws must be correct (timing)
- Once the first pair is in the correct orientation, the remaining elements are arranged "face to face". It is common to move the first pair back out toward the end of the shaft so the end profiles of each element can be aligned so that they match
- Assemble the screw elements onto the shafts following the design drawing
- Complete the screw shaft assembly by threading on a pair of screw tips and tightening just hand-tight for now. The final tightening will be done after the screws are in the extruder

Note: Proceed carefully, wiping the element end-faces each in its turn. Be sure to double check their alignment, especially on splined shafts. This will ensure the ability of the screws to turn properly as a set and expedite the reinstallation of the completed assembly

- The assembled screws can now be double checked by ensuring the gap between the completed assemblies is spaced consistently. The tolerance between the elements is very tight, but a gap

should be visible. A flashlight can be used to confirm visibility and check that the line of light running between the elements remains constant



Note intermesh gap between screws

- Install the screw shaft couplings on the gearbox output shafts
- Coat the shaft splines liberally with an anti-seize compound

As an assembly check, lay the 2 screws on a flat table or floor so they're intermeshed correctly, and roll the screw set back and forth, while looking for any interferences (co-rotating screws only). A set of elements incorrectly installed will either rub together or tend to push the 2 screws apart where they intermesh.

#### **Reinstalling the screws into the twin screw extruder:**

To reinstall the completed screw shaft assemblies, first ensure that the gearbox output shafts and couplings are in the correct position, which means the setscrews or coupling pointers are facing outwards at 9:00 and 3:00 o'clock. To rotate the output shafts of the gearbox, either turn the motor input coupling by hand (with the main power shut off and locked out), or rotate the motor very slowly using the drive. Orient the screw tail-shafts the same way (9:00 and 3:00 o'clock), and hold the 2 screws close together so they're intermeshed.

- Remove any hardened material from the barrel bores
- Vacuum all loose debris from connecting piping and barrel bore
- Ensure proper alignment of the barrels
- Visually check for possible interference from plugs, adapters, and devices
- Insert the timed screw shaft assembly level and parallel
- DO NOT FORCE the shafts further if an interference is felt
- Once the screw shaft splines clear the seal plate, coat the splines with anti-seize
- Push the shaft assembly the remaining distance into the coupling
- Complete the screw shaft coupling installation

Once the screws are fully engaged in the couplings, check to see that both screw tips are protruding from the barrel end-flange by the same distance. If they're not, something is wrong and the screws should be removed and the assembly checked.

At this time, do the final tightening of the screw tips using the tip wrench supplied with the machine. Remember that the tips have a left-hand thread on a co-rotating extruder. Tighten each tip until the gearbox/motor starts to rotate. That's tight enough. Do not use any kind of "cheater pipe" on

the tip wrench to torque the tips tighter. As a final check, with the speed set point very low (1-2 RPM) start the main drive and rotate the screw set through a few revolutions. If everything seems OK, increase the speed to 20 RPM and listen for any knocking sounds. Minor clicking sounds are normal because the screws/barrels are dry. As material is introduced clicking sounds will usually go away.

### **List of recommended tools/parts for your maintenance shop**

Having the right tools can make life a lot easier. The well-equipped extrusion shop should have the following items:

- 6 ft. and 10 ft. folding ladder
- Work bench with wood top, with a 6" vise mounted to one end
- Work gloves
- Insulated hot work gloves
- Propane torch
- Misc. size wire brushes
- Copper gauze
- Anti-seize for any heated bolts, for instance on the die
- Full set of common hand tools
- Flashlight
- Plastic buckets
- Fire extinguishers, situated close to the machines
- Pry bar (crowbar)
- Duct tape
- Electrical tape
- Cable ties
- Fluidized bed high temperature cleaner, or an oven made for cleaning plastic off of metal parts
- Resin scoopers
- Rubber gloves (disposable type)
- First-aid kit
- Wire brushes, both flat and round
- Brass scraper (or stiff brass putty knife)
- High-temp. glass fiber insulation, roll of 1/4" x 2" (to wrap dies or melt pipe adapters)
- Mold release spray
- Wood or plastic paint stirrers (for poking the feed or vent ports)
- Copper gauze
- Sandpaper, 220 and 320 grit
- Shop vac.
- Metric combination open end/box end wrenches
- Channel lock pliers
- Needle nose pliers
- Vise-grips
- Utility knives
- Hacksaw
- Pipe wrenches, 6" and 12"
- Files, both flat and round
- Wire stripper
- Kit with misc. electrical wire and connectors, wire nuts
- Screwdrivers, wrenches, hammer, allen wrenches (Metric)
- Digital multimeter
- Clamp-on inductive ammeter with AC and DC capability
- Teflon tape
- High-temp fiberglass tape, 1" wide
- 1/2" electric drill, and full set of drill bits

- Drill press
- 4.5" angle grinder, with both sanding and abrasive cutoff disks
- Dremel moto-tool, with all the available attachments

Spare parts that should always be kept on-hand:

- Fuses
- Thermocouples
- Thermocouple bayonet adaptors
- Barrel heaters
- Die heaters
- Solid state relays, correct type for heat zones
- Dynisco pressure transducer
- Oil filter for gearbox
- Correct grade of oil for gearbox
- Gaskets and O-rings for vacuum stack assembly
- Barrel cooling hoses
- Solenoid valve
- Screws/barrels/shafts (depending upon type installation)
- Screw tips



Some of the tools you'll use