



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Screw Removal 1

Modified on Sunday, 01 February 2015 05:10 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Vents 1](#) » [Drive Train](#) » **[Screw Removal 1](#)**




Screw Removal 1
Vol. 17 #4, Mar. 1991

Before removing a screw from an extruder, disconnect the die and breaker plate, and run ultra high molecular weight (>1 mm) polyethylene through the open discharge. It will not melt, but will strip the screw free of melted polymer.

See also:

- [Extruder screw won't push out](#)
- [Screw removal 2](#)
- [Screw removal 3](#)
- [Screw removal 4](#)
- [Oak persuaders](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .