



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Easy Screw Disassembly

Modified on Sunday, 01 February 2015 06:01 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Screw Position](#) » [Drive Motor Start Up](#) » [Easy Screw Disassembly](#)

Easy Screw Disassembly
Vol.20 #2, July 1993


A convenient trick to ease screw disassembly from a keyed or splined shaft in the lab is to use mold release coating on the shafts.

It does not readily migrate into the product or onto the screw surfaces and the elements easily slide off the shafts, for both hot and cold.

See also:

- [Mold release](#)
- [Screw cleaning 1](#)
- [Screw cleaning 2](#)
- [Screw removal 1](#)
- [Screw removal 2](#)
- [Screw removal 3](#)
- [Screw removal 4](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .