



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

 »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Lubricate Screw Shank

Modified on Sunday, 01 February 2015 10:41 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Hot Gearbox 2](#) » [Liquid in Feed](#) » **Lubricate Screw Shank**

Lubricate screw shank
Vol.21 #2, Oct. 1994

When changing screws, be sure to lubricate the shank. This can prevent two problems:

- 1) Rusting of screw in place.
- 2) Fretting and/or abrasion due to misalignment.

See also:

- [Anti seize compounds](#)
- [New screw shank lubricant](#)
- [Screw installation 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)