



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Adapter Flange Leak

Modified on Sunday, 01 February 2015 10:48 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Changing Resin Types](#) » [Assembling a Screen Pack](#) » [Adapter Flange Leak](#)


Adapter flange leak
Vol. 21 #3, Dec. 1994

When a leak occurs in an adapter flange, be sure to clean all flange surface area, torque the bolts properly prior to applying heat, and then re torque the bolts when the line is fully heated and before running plastic through the line.

See also:

- [Adapter flow](#)
- [Leaks](#)
- [Restrictive adapter](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .