



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Remove Buildup

Modified on Monday, 02 February 2015 12:32 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

(10) » [Restrictive Adapter](#) » [Hand Held Pyrometer](#) » **Remove Buildup**

Remove Buildup
Vol. 25 #1, May 1998


Many times after the screw is removed from the barrel and during the cleaning process, material is forced back into the gearbox or screw seat. This will cause the screw to either not fit upon installation, or cause the screw to not firmly seat, which can cause future mechanical and process problems. Be sure to prevent the buildup of material in this area.

- Mark Sewak, LCI Corp.

See also:

- [Screw cleaning 1](#)
- [Screw cleaning 2](#)
- [Screw inspection](#)
- [Screw performance](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .