



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



TC moisture

Modified on Monday, 02 February 2015 12:58 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

(10) » [Breaker Plates](#) » [Closed Loop Dryer](#) » **TC moisture**

TC moisture

Vol. 26 #2, September 1999 and Vol. 26 #3, December 1999


After an extended shutdown, many times the temperature readings may fluctuate. This is normally caused by condensation, which collects in the t/c well and adapter. Rust then forms at the contact point between the t/c and barrel.

- Mark Sewak, LCI Corp.

See also:

- [Temperature control](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .