



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Die Pressure Variation

Modified on Monday, 02 February 2015 01:22 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Improve Melt Quality](#) » [Extruder Screw Won't Push Out](#) » **Die Pressure Variation**

Die Pressure Variation
Vol. 27 #3, December 2000


When significant quantities of recycled plastics are used, die pressure variations may not be due to extruder surging. Many times, these pressure variations are related to viscosity changes in the melt stream due to the different melt indexes of the materials being processed.

- Dan Smith, Maag Pump Systems Textron

See also:

- [Vent flow 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .