



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  [»](#)

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Start Up Help

Modified on Sunday, 01 February 2015 01:29 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [RPM Meters](#) » [Thermocouple Connections 1](#) » [Start Up Help](#)


Vol. 16 #2, Dec. 1989 - Start up help

When shutting down a blown or cast film system, put a 1% antioxidant concentrate into the system just before pulling the switches. This is particularly effective in protecting coextrusion systems from cross linked gels caused by heat aging during final cooling and heating during start up.

See also:

- [Mark the bubble](#)
- [Coextrusion control](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .