



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Screen Packs 1

Modified on Sunday, 01 February 2015 01:29 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Thermocouple Connections 1](#) » [Start Up Help](#) » [Screen Packs 1](#)

Vol. 16 #2, Dec. 1989 - Screen Packs 1


When using fine screens in a pack, use a coarser screen as the first upstream screen to catch large dirt particles, to add a little life to the fine screen.

To help prevent blowout, remember to back up fine screens using progressively coarser ones downstream.

See also:

- [Assembling screen packs](#)
- [Screen packs 2](#)
- [Screen utilization](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .