



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki


»

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration

- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# LLDPE Lensing

Modified on Sunday, 01 February 2015 04:40 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

(10) » [Hoppers](#) » [Anti Seize Compounds](#) » **[LLDPE Lensing](#)**

Vol 17 #1, Feb. 1990 - LLDPE Lensing


When running granular LLDPE and color concentrate on larger diameter machines, lensing or voids frequently occur because some of the fine particles tend to stick to the hot root diameter in the feed section of the screw.

Using screw cooling, but only to the end of the feed section, will prevent sticking, air entrapment and lensing.

See also:

- [Screw cooling](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .