



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



# Nylon Purge

Modified on Sunday, 01 February 2015 04:54 PM by [mpieler](#) Categorized as [Extrusion Hints](#) [\(10\)](#) » [Check New Screws](#) » [Pressure Transducers](#) » [Nylon Purge](#)

Nylon Purge  
Vol. 17 #2, July 1990

When trying to purge a system of nylon, in order to begin running polyethylene, try running GP polystyrene above the nylon melting point first, then lower the GP styrene to polyethylene melt temperature before purging with PE.

See also:

- [Purging](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)