



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Oak Persuaders

Modified on Sunday, 01 February 2015 05:07 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Calibrate Transducers](#) » [Feed Throat Cooling](#) » **[Oak Persuaders](#)**


Oak Persuaders
Vol. 17 #4, Mar. 1991

Use a good, solid, oak 2 X 4 to remove segmented screw sections that are stuck on keyed or splined shafts. This allows direct force to be used without damage resulting from metal to metal contact. (Even brass persuaders can be damaging.)

See also:

- [Extruder screw won't push out](#)
- [Screw removal 1](#)
- [Screw removal 2](#)
- [Screw removal 3](#)
- [Screw removal 4](#)
- [Segmented screws](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .