



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Threaded Commutators

Modified on Sunday, 01 February 2015 05:22 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Throat Cooling](#) » [Brush Wear Forecasting](#) » **[Threaded Commutators](#)**

Threaded Commutators
Vol. 19 #1, Feb. 1992


I've seen a fair number of DC drive motors with threaded (a fine sort of grooving) commutators.

Threading can be caused in many ways, but, chances are, the brush current density is too low.

See also:

- [Brush wear forecasting](#)
- [DC drive failure](#)
- [Drive motor start up](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .