



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Thermocouple Connections 2

Modified on Sunday, 01 February 2015 05:23 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Threaded Commutators](#) » [Pressure Transducer Handling](#) » **[Thermocouple Connections 2](#)** 

Thermocouple Connections 2

Vol. 19 #1, Feb. 1992


A field expedient method for providing thermocouple connector strain relief is to overwrap the rear of the thermocouple connector with wire and then tape over the wire with glass (high temperature) tape.

Go back and forth over the union of wire and connector body 4 to 6 times, for best results.

See also:

- [Barrel thermocouple maintenance](#)
- [Thermocouple connections 1](#)
- [Thermocouples](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .