



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Material Clean Out

Modified on Sunday, 01 February 2015 10:06 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Temperature Measurement 1](#) » [Shaft Leakage](#) » **Material Clean Out**

Material clean out
Vol.20 #3, Dec. 1993


Remember, when testing a new material, it is well worth any extra time to clean out hoppers and loaders and conveying lines to eliminate any cross contamination.

If you see unexpected results, you don't want to second guess that it may be a resin contamination problem.

See also:

- [Changing resin types](#)
- [Clean out dust and flake](#)
- [Extrusion trials](#)
- [Hopper segregation](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .