



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  [»](#)

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Vent Openings

Modified on Sunday, 01 February 2015 10:13 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Overfilled Gearbox](#) » [Early Detection](#) » **[Vent Openings](#)**

Vent Openings
Vol.20 #3, Dec. 1993


Look at the vent openings. Are they clean? Do they need to be heated? Is condensation dripping back into the process?

Both conditions can lead to poor product quality.

See also:

- [Vent bleed](#)
- [Vent design](#)
- [Vent flow](#)
- [Vent insert design](#)
- [Vent plugging](#)
- [Vents 1](#)
- [Vents 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .