



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration


- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# Water Piping

Modified on Sunday, 01 February 2015 10:18 PM by [mpieler](#) Categorized as [Extrusion Hints](#)   
(10) » [Temperature Measurement 2](#) » [Turnaround Delays](#) » [Water Piping](#)

Water piping  
Vol.21 #1, June 1994


It is common practice to pipe the extruder's water cooling supply for the feed section and gear box in parallel with numerous other devices like cooling rolls or even other extruders.

If one of the flow paths has a low resistance to water flow, most of the cooling water will take that path and the extruder will not get enough cooling for proper operation. In these cases, it is necessary to add a booster pump in the supply line to the extruder.

See also:

- [Cooling water](#)
- [Cooling water flow](#)
- [Water cooling](#)
- [Water valve off](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .