



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Tools

Modified on Sunday, 01 February 2015 11:39 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Extruder Mounts](#) » [Vacuum Pump Discharge](#) » **Tools**

Tools

Vol. 23 #3, Dec. 1996


When working on an extruder, use soft metal or plastic implements to avoid chipping of hardened screw and barrel surfaces.

- Paul Andersen

See also:

- [Brass tools 1](#)
- [Brass tools 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .