



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration


- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



## Seated TCs

Modified on Monday, 02 February 2015 12:37 PM by [mpieler](#) Categorized as [Extrusion Hints](#)   
(10) » [Sweep Up](#) » [Chromium Plating Test Solution](#) » [Seated TCs](#)

Seated TCs  
Vol. 25 #2, Sept. 1998


For better barrel temperature control, check thermocouples on a regular basis to make sure they are seated properly.

- Paul Andersen Krupp, Werner Pfeleiderer.

See also:

- [2 machines, 1 material](#)
- [Barrel thermocouple maintenance](#)
- [Temperature controller calibration](#)
- [Thermocouple connections 1](#)
- [Thermocouple connections 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .