



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Purge 2

Modified on Monday, 02 February 2015 12:42 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Monitor Heaters](#) » [Product Variations](#) » [Purge 2](#)

Purge 2

Vol. 25 #2, Sept. 1998


A fast, effective purge material to use for cleaning out an extruder experiencing gels is to add a concentrate containing a polymer processing aid and antioxidant additives. Adding it to the extruder and running it for an hour, at full production rates, will help clean the extruder and die.

- Tom Butler, The Dow Chemical Co.

See also:

- [Nylon purge](#)
- [Purge](#)
- [Purge 2](#)
- [Purge compound](#)
- [Purge material](#)
- [Purging gels](#)
- [Purge - close vent](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .