



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Profile Die Design

Modified on Monday, 02 February 2015 01:10 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Extruding Amorphous Materials](#) » [Checking Extrusion Output Rates Without the Use of a Calculator](#) » [Profile Die Design](#)



Profile Die Design
Vol. 27 #1, March 2000


Good profile die design starts with an understanding of the rheology (study of melt flow) of the thermoplastic that will ultimately be used to extrude product from the profile die. Two key factors that one must study are die swell (actually the swell of the thermoplastic as it exits the die lip) and land length ratio (the length of steel that runs parallel to the melt path). Material suppliers will share the shear/stress curves for predictability of a thermoplastic at a given rate.

- Dan Cykana, Bemis Mfg. Co.

See also:

- [Rheology](#)
- [Rules of thumb](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .