



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Extruding Amorphous Materials 2

Modified on Monday, 02 February 2015 01:24 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Die Pressure Variation](#) » [Vent Flow 2](#) » **Extruding Amorphous Materials 2**

Extruding amorphous materials 2
Vol. 27 #3, December 2000

Amorphous materials can be difficult to extrude. Severe starve feeding during startup can sometimes get the extruder "primed" so that it will feed at full rate.

- Steve Derezinski, Eastman Kodak Co.

See also:

- [Extruding amorphous materials](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)