



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration

- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# Aligning a Blown Film Tower

Modified on Monday, 02 February 2015 01:26 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Portable Wet/Dry Vacuum Cleaner](#) » [Heat Exchanger](#) » **[Aligning a Blown Film Tower](#)** 

Aligning a Blown Film Tower  
Vol. 27 #3, December 2000


When aligning a blown film tower, especially if it is a tall one that pops up above the normal factory roof, don't forget to allow for a small amount of correction for tower movement, based on prevailing winds. In other words, if it is really windy out, wait until a day where it is pretty calm.

- Bill Davis, Poly-America

See also:

- [Pressure wash extrusion lines](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .