



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Polymer Degradation

Modified on Monday, 02 February 2015 01:26 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Heat Exchanger](#) » [Aligning a Blown Film Tower](#) » **[Polymer Degradation](#)**

Polymer Degradation
Vol. 27 #3, December 2000

Chrome plated screws are a good way to reduce polymer degradation and plate out on the screw.

- John Wagner, JWV Enterprises

See also:

- [Chemical purge compound](#)
- [Gear pumps](#)
- [Gels 3](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)