



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration


- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



## Screen Pack

Modified on Thursday, 26 February 2015 03:51 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 


[\(10\)](#) » [Feed Backup When Working with Powder](#) » [Purging \(2\)](#) » **Screen Pack**

Screen Pack  
Vol. 31 #2, Fall 2004

When adding a screen pack to an extrusion line, be sure to add a pressure transducer and gauge upstream so that screen blinding and associated pressure increase can be quantified to determine correct screen change cycle.

– Dan Smith PSI, Polymer Systems, Inc.

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .