



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

 >>

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration

- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# Apply Anti Seize

Modified on Thursday, 26 February 2015 04:06 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Purging Compounds](#) » [Reduce Temperature Variation](#) » **[Apply Anti Seize](#)**

Apply Anti Seize  
Vol. 33 #1, Summer 2006

When replacing a large number of die bolts, it takes a lot of time to paint each bolt with anti seize compound. To speed up this process, and reduce the mess, put on a rubber glove and apply the compound with your fingers.

– Chris Luker, S&L Plastics

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)