



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Extruder Log Book

Modified on Sunday, 01 February 2015 06:05 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Purging](#) » [Worn Screw](#) » **Extruder Log Book**

Extruder log book
Vol.20 #2, July 1993

We keep a log book on each line. This book is about 8 1/2" x 11" wire bound. Each hour, temperature and conditions are reported.

When a problem comes up, certain changes are made to correct. Sometimes these changes don't work but they are recorded anyway. I have referred to the log many times it's a great help.

See also:

- [Data collection 1](#)
- [Document/document/document](#)
- [Extrusion data sheets](#)
- [Screw performance](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)