



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

 »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Lower Feed Zone Temperature

Modified on Sunday, 01 February 2015 10:10 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Segmented Screws](#) » [Simulations](#) » [Lower Feed Zone Temperature](#)



Lower feed zone temperature
Vol.20 #3, Dec. 1993

When an extruder is having problems supplying good melt quality, one item to check is the feed zone temperature set point.

Many times more mixing can be obtained by reducing the feed zone temperature.

See also:

- [Feed throat temperature](#)
- [Melt delivery](#)
- [Reversed temperature profile 1](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)