



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki



Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



# Zone Cooling Check Up

Modified on Sunday, 01 February 2015 10:13 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Early Detection](#) » [Vent Openings](#) » **[Zone Cooling Check Up](#)**



Zone cooling check up  
Vol.20 #3, Dec. 1993

Is the cooling water clean?  
Are the jacket hoses plugged or crimped?  
Are the solenoids stuck?  
Are the band clamps loose?  
Check the barrel surface temperature with a pyrometer.

See also:

- [Barrel zone override](#)
- [Cooling water](#)
- [Hand held pyrometers](#)
- [Hose clamp safety](#)
- [Water cooling](#)
- [Water valve off](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)