



## Navigation



### Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

### Search the Wiki

 >>

### Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

### Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

### Administration

- [Administration](#)
- [File Management](#)

### Brought to you by:

The SPE Extrusion Division Board of Directors



# Spin Dryer

Modified on Sunday, 01 February 2015 10:45 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Preventative Maintenance List](#) » [Drive Speed Controller](#) » [Spin Dryer](#)



Spin Dryer  
Vol. 21 #3, Dec. 1994

If you use an underwater pelletizer with a centrifugal spin dryer, the screen may be fouled resulting in increased product moisture contents.

See also:

- [Underwater pelletizer](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)