



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Transducer Accuracy

Modified on Sunday, 01 February 2015 11:15 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Vent Design](#) » [Gearbox Oil Level](#) » **Transducer Accuracy**

Transducer Accuracy
Vol. 22 #3, Dec. 1995

In spite of advances in pressure transducers, the reading is still a function of the torque used to install it and the operating temperature of the process.

For sensitive applications (+/- 5% of scale), calibrations should be performed at operating temperature and use a torque wrench to install.

See also:

- [Pressure transducers](#)
- [Pressure transducers 2](#)
- [Transducer calibration](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)