



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Output Calculations

Modified on Sunday, 01 February 2015 11:20 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

(10) » [Leaks](#) » [Gear Pump Assembly](#) » **Output Calculations**



Output Calculations
Vol. 22 #3, Dec. 1995


A quick, accurate way to check lb over hour output rates from a feeder or extruder is to collect the discharge for 80 seconds, weigh it in gms., and then move the decimal point one place to the left, as follows:

1 lb/hour = x gms./80 sec. (2.2lbs./1000 gms.) (3600sec./hr.) = 0.10 x lb/hr.

See also:

- [Checking extrusion output rates without the use of a calculator](#)
- [Extruder output](#)
- [Output rate check](#)
- [Output rates](#)
- [Output variation 1](#)
- [Output variation 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .