



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Gear Pumps

Modified on Monday, 02 February 2015 12:19 AM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Transitioning](#) » [Protect the Pump](#) » **[Gear Pumps](#)**

Gear Pumps
Vol. 24 #2, Sept. 1997


For small extrusion process involving gear pumps for pressurizing filament or profile dies, minimizing pump inlet pressure can reduce degradation and melt temperature of heat and shear sensitive polymers.

- Paul Andersen, Werner & Pfleiderer

See also:

- [Gear pump assembly](#)
- [Gear pump lubrication](#)
- [Gear pump wear](#)
- [Inconsistent gear pump output](#)
- [Polymer degradation](#)
- [Pump acceleration rate](#)
- [Suction pressure](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .