



## Navigation



### Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

### Search the Wiki

 »

### Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

### Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

### Administration

- [Administration](#)
- [File Management](#)

### Brought to you by:

The SPE Extrusion Division Board of Directors



# Bolt Cleaning

Modified on Monday, 02 February 2015 12:24 AM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Melt Delivery](#) » [Purge](#) » **[Bolt Cleaning](#)**

Bolt cleaning  
Vol. 24 #3, Dec. 1997

A bolt type screen changer should be cleaned and lubricated after each 10 screen changes.

This can be accomplished by polishing the bolt with copper gauze and applying a spray lubricant recommended by the manufacturer.

- Dan Smith, LCI Corp

See also:

- [Assembling a screen pack](#)
- [Screen changing with a continuous screen changer](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .