



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration

- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



# Mold release

Modified on Monday, 02 February 2015 12:25 AM by [mpieler](#) Categorized as [Extrusion Hints](#) 

(10) » [Color Changes](#) » [Insulate Vent](#) » **Mold release**

Mold Release  
Vol. 24 #3, Dec. 1997


A good, high temperature mold release sprayed on segmented screw shafts makes frequent disassembly easy during process development and tends not to migrate and contaminate the product.

- Ken Powell, Becton Dickinson Research Center

See also:

- [Easy screw disassembly](#)
- [Segmented screws](#)
- [Shaft leakage](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .