



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Heater Burnout

Modified on Monday, 02 February 2015 12:29 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Rheology](#) » [Chemical Purge Compound](#) » **Heater Burnout**

Heater Burnout
Vol. 25 #1, May 1998

Prevent heater burnout and get longer heater life time, by making sure there is good contact between heater and barrel. Check, on a regular basis, to make sure all are secure.


The more an extruder barrel temperature is cycled between high and low temperature, the more frequently the need to check.

- Paul Andersen Krupp, Werner & Pfleiderer Corp.

See also:

- [Barrel heaters](#)
- [Loose heaters](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .