



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Extruder Output

Modified on Monday, 02 February 2015 01:10 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Profile Die Design](#) » [Corona Treatment](#) » **Extruder Output**

Extruder Output
Vol. 27 #1, March 2000


When considering the theoretical and actual output of an extruder, the density change of any specific polymer from solid to melt phase must be considered. For instance, the solid density of polyethylene is .92-.96, however, the melt density ranges from .72-.76.

- Dan Smith, Maag Pump Systems

See also

- [Checking extrusion output rates without the use of a calculator](#)
- [Output calculations](#)
- [Output rate check](#)
- [Output rates](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .