



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

 »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Melt Pressure Indicator

Modified on Monday, 02 February 2015 01:15 PM by [mpieler](#) Categorized as [Extrusion Hints](#)

[\(10\)](#) » [Drying Temperature](#) » [Document/Document/Document](#) » [Melt Pressure Indicator](#)

Melt Pressure Indicator
Vol. 27 #2, November 2000

Always include a melt pressure indicator to assist in the resolution of extrusion problems. Absolute extrusion pressure indication and variation in extrusion pressure are key in the diagnosis of problems, as well as improvement of the overall extruded product.

- Dan Smith, Maag Pump Systems

See also:

- [Melt pressure](#)
- [Output variation 1](#)
- [Output variation 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#)