



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration

- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Angel Hair (Extrusion Hint)

Modified on Monday, 02 February 2015 01:25 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Gas Compressor](#) » [Drive Ratio](#) » **[Angel Hair \(Extrusion Hint\)](#)**

Angel Hair (Extrusion Hint)
Vol. 27 #3, December 2000


Material handling and conveying problems, due to "angel hair", can be a common complaint when purchasing the material in bulk truck and rail car quantities. A quick and reliable solution is to install a removable screen at the discharge of your silo. The removable screen will catch the angel hair, which can be removed periodically before it inhibits material flow. These removable screens are available through your auxiliary equipment supplier.

- Pete Stoughton, Conair

See also:

- [Screen utilization](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .