



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  [»](#)

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Storage of Extruders

Modified on Sunday, 01 February 2015 10:34 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Storage](#) » [Barrel Thermocouple Maintenance](#) » [Storage of Extruders](#)


Storage of Extruders
Vol.21 #2, Oct. 1994

An extruder can be seriously damaged in storage by freezing. Water is often trapped in some areas after disconnecting all water lines and draining the system. Cast iron feed throat jackets are particularly susceptible sometimes without a low point drain. They must be blown out with air or filled with antifreeze. Heat exchangers are also often piped so they will not drain.

See also:

- [Cooling water](#)
- [Extruders](#)
- [Extruder cooling](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .