



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki

  »

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration


- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



## Output Rates

Modified on Sunday, 01 February 2015 05:11 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Screw Removal 1](#) » [Brass Tools 2](#) » **Output Rates**

### Output Rates

Vol. 17 #4, Mar. 1991


Many times, it is necessary to cut lengths of product over a period of time and weigh to determine lbs./hr. Especially small profiles and tubing.

Instead of 60 seconds, use 36 seconds or a multiple of it. There are 3600 seconds in an hour and a 36 second rate X 100 gives lbs./hr. directly.

#### See also:

- [Checking extrusion output rates without the use of a calculator](#)
- [Extruder output](#)
- [Output calculations](#)
- [Output rate check](#)
- [Output variation 1](#)
- [Output variation 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .