



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Segmented Screws

Modified on Sunday, 01 February 2015 10:09 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Cooling Water](#) » [Hopper Segregation](#) » [Segmented Screws](#)

Segmented Screws
Vol.20 #3, Dec. 1993


When assembling a segmented screw, lapping the ends of the elements minimizes polymer leakage along the shaft.

It is common to have burrs develop at the flight tips that prevent close mating of the surfaces. Moving the element in a figure 8 pattern on 400 grit sandpaper on a smooth, flat surface will remove the burrs without causing any problem.

See also:

- [Mold release](#)
- [Oak persuaders](#)
- [Shaft leakage](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .