



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division Board of Directors



Transducer Calibration

Modified on Sunday, 01 February 2015 11:01 PM by [mpieler](#) Categorized as [Extrusion Hints](#) (10) » [Corona Treater Power](#) » [Water Valve Off](#) » **Transducer Calibration** 

Transducer Calibration
Vol. 22 #2, Sept. 1995


When debugging electronics for pressure transducers, a deadweight tester is invaluable.

This allows a known load to be placed on the transducer so the entire system can be checked.

See also:

- [Pressure transducer handling](#)
- [Pressure transducers](#)
- [Pressure transducers 2](#)
- [Transducer accuracy](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .