



## Navigation



## Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

## Search the Wiki


»

## Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

## Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

## Administration


- [Administration](#)
- [File Management](#)

## Brought to you by:

The SPE Extrusion Division  
Board of Directors



## Brass Bolts on Flange Collar

Modified on Sunday, 01 February 2015 11:17 PM by [mpieler](#) Categorized as [Extrusion Hints](#)   
(10) » [Transducer Removal](#) » [Reinstalling a Screw](#) » **Brass Bolts on Flange Collar**

Brass bolts on flange collar  
Vol. 22 #3, Dec. 1995


Brass bolts are used on extruder flange collars and should be tightened to specified torques.

However, the threads on a brass bolt can be easily sheared, therefore, brass bolts should be replaced on a frequent basis.

See also:

- [Brass tools 1](#)
- [Brass tools 2](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .