



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki


»

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Fouling

Modified on Sunday, 01 February 2015 11:41 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 

[\(10\)](#) » [Vents 2](#) » [Cooling Water Flow](#) » **Fouling**

Fouling

Vol. 23 #3, Dec. 1996

If devol performance declines gradually, check your traps and vent lines for fouling.


It is amazing what condenses and solidifies in these lines over time.

- Ken Powell

See also:

- [Vent plugging](#)
- [Vent port fouling](#)

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .