



Navigation



Extrusion 1-0-Wiki Pages

- [Main Page](#)
- [Best Papers](#)
- [Book Reviews](#)
- [Consultants Corner](#)
- [Extruder Software](#)
- [Extrusion Hints](#)
- [Safety](#)
- [Shop Tools](#)
- [Sponsors](#)
- [Technical Articles](#)

Search the Wiki

  »

Viewing/Creating

- [Random Page](#)
- [Create a new Page](#)
- [All Pages](#)
- [Categories](#)

Account Management

- [Login/Logout](#)
- [Language Selection](#)
- [Your Profile](#)
- [Create Account](#)

Administration


- [Administration](#)
- [File Management](#)

Brought to you by:

The SPE Extrusion Division
Board of Directors



Adjustable Pressure Valve


Modified on Thursday, 26 February 2015 03:41 PM by [mpieler](#) Categorized as [Extrusion Hints](#) 
(10) » [Blender Problems](#) » [Adhesion in Extrusion Coating](#) » **Adjustable Pressure Valve**

Adjustable Pressure Valve
Vol. 31 #2, Fall 2004

Using an adjustable pressure valve in the extrusion process can upset thermal homogeneity, making die adjustment more difficult. Consider using a static mixer to reduce thermal gradients.

– Dan Smith PSI, Polymer Systems, Inc.

Return to [Extrusion Hints](#)

Some of the icons were created by [FamFamFam](#) .